

NB: Attaching a HS shadow to a SS blokart

All HS (high strength steel) now come supplied with two short sleeves that are used if you are attaching the HS shadow to a SS (stainless steel) blokart.



1. Slide a sleeve over the rear axle stub on the shadow ensuring the sleeve hole locates with the existing spring button.



2. Slide the other sleeve over the shortened axle that will go into the right side of the SS blokart chassis.

3. Attach the HS shadow to the SS blokart as per instructions.



Another great product to emerge from the secret chambers of the R&D team is the shadow. Please follow the assembly instructions carefully to attach the shadow properly.

NB: The shadow is designed to go on the left hand side of the blokart only.

The SS shadow will not fit early HS blokarts prior to chassis no. 3444



Assembly Instructions

Place the 6 loose components (2 shortened axles*, 3 shadow blocks [incl. one spare block] and safety bar top section) to one side. Remove the large star knobs at the front and centre of the shadow. Each star knob is unique so ensure they do not get mixed up.

1. Pull the shadow backrest up into place and make sure the button clicks into place.



2. Swing down the small arm on the safety bar and attach to the shadow chassis with the small star knob.



3. Attach the loose top section of the shadow safety bar to the main section on the shadow with the toggle pin.

4. Assemble the blokart less its rear wheels and lay over on right hand side with one rear wheel resting under the mast base.



5. Lift shadow over blokart and insert rear axle stub of the shadow into the rear axle tube of the blokart chassis. Do not locate the spring button into the chassis hole yet.

6. Rest front 'C' clamps of the shadow over chassis and rear seat back, lifting rubber protectors out of the way.



7. Push firmly and click button into place locating all 3 clamps.

8. Insert the orange shadow blocks into the front and centre clamps and secure with star knobs - the longer star knob goes in the centre clamp, you may need to push down on the chassis to allow you to secure the front clamp.



9. Undo the shadow foot bar star knob and refasten with plastic clamp around the blokart foot bar.



10. Attach the safety bar to the blokart mast base by removing the left tri-knob, sliding the safety bar over the mast base stud and then re-tightening the tri-knob and attaching the safety clip. This is easiest done when the kart is still on its side.

11. Using the shortened axles supplied with the shadow re-attach both the wheels to the shadow chassis.



You are now ready to rig up and go!

Warning:

- * Do not attempt to sail the blokart with the shadow on two wheels. If a wheel comes off the ground immediately release the sheet rope.
- * Never use the Shadow with the Deuce accessory.
- * The shortened axles are used to narrow the extended width of the kart due to the shadow.